



LAS-1 brannalarmtablå

Dette bygget er utstyrt med automatisk brannalarm med lokale avstillingstablåer.

Prinsipp:

Alarmer som utløses av røykdetektorer i leiligheter eller lignende varsler først lokalt. Resterende bygningsmasse og døgnbemannet vaktstasjon/brannvesen varsles ikke ved lokal alarm.

Beboere kan da kvittere på trykknappen hvis det er en feilalarm (fra matos, damp osv.) innen 2 minutter. Deretter kan det luftes ut i inntil 5 minutter, for så å tilbakestille alarm. Prosedyren kan gjentas til alarmeren er eliminert.

I reelle branntilfeller der slokking vil være uforsvarlig skal ikke tablået benyttes, og brannalarmanlegget vil da utløse full alarm etter 2 minutter. Denne forsinkelsen gjelder kun boenheter, og ikke ellers i bygget. Ved lokal alarm i leiligheten vil rød lysdiode på bryteren tennes.

Dersom denne ikke lyser, evakuer bygget til sikkert sted da brannalarm er utløst et annet sted i bygningen. Vent på brannvesen og følg deres instruksjoner.



Ved lokal alarm vil lysdiode være tent.

Reelt branntilløp

Utløses brannalarmen av et reelt branntilløp i leiligheten så gjør følgende –

- Er brannen håndterbar så slokk brannen og følg anvisning til høyre (Feilalarm). Ring brannvesen og forklar situasjonen. Husk at røyken er svært giftig, og kan sette deg ut av spill etter bare noen få åndedrag.
- Er brannen uhåndterbar, så lukk dører og vinduer for å begrense spredningen av brann og røyk. Evakuer leiligheten, finn nærmeste brannmelder og trykk på denne slik at brannalarmen utløses i bygget. Ring brannvesen og meld fra.
- Orienter brannvesen når de ankommer.

Feilalarm

Når en lokal alarm utløses og denne skyldes en feilalarm fra f.eks. matos eller vanddamp –



Trykk på rød knapp innen 2 minutter. Lokale alarmorganer blir da slått av. Luft ut (maksimalt 5 minutter).



Trykk på grønn knapp for å tilbakestille alarm. Rød lysdiode vil da slokke. Utløses brannalarmen igjen, kan samme fremgangsmåte utføres på nytt.



LAS-1 Fire Alarm Local Silencer

This building is equipped with fire alarm and local alarm silencers for the dwellings.

Principle:

Fire alarms triggered by smoke detectors in housing units or other building areas will first alert locally. Other building areas, nor the security firm / fire department, will not be affected by a local alarm.

If a false alarm is triggered (from cooking smoke, steam etc.), the residents can press the red silencer-button within 2 minutes. This enables the occupant to open the windows and clear the smoke up to 5 minutes, before resetting the alarm with the green button. Procedure can be repeated until the alarm is eliminated.

Do not use this switch in case of a fire where extinguishing is not safe. The fire alarm will alert the whole building after 2 minutes. This delay applies only to the dwellings and not elsewhere in the building.

In case of a local alarm in the housing unit, the red LED on the switch will turn on. If the LED is not lit means that the alarm is triggered another place in the building. Evacuate the building to a safe place. Wait for the fire brigade, and follow their instructions.



A local alarm will trigger the LED.

Real fire

If the fire alarm is triggered by a real fire, do as follows –

- If the extinguishing of the fire is safe follow the instructions on the right (False Alarm). Call fire brigade and explain your situation. Remember that smoke is very toxic, and inhaling smoke for a short time can cause immediate (acute) effects.
- If the fire is unmanageable, close all windows and doors to limit the spread of fire and smoke. Evacuate the housing unit and find the nearest manual call point and press it. The fire alarm will then go off in the building. Call the fire department and inform them about the situation.
- Brief the fire brigade when they arrive.

False alarms

In case of false local alarm triggered by for example cooking-smoke or steam –



Press the red button within 2 minutes. The local evacuation signal equipment will then be turned off. Clear out smoke (maximum 5 minutes).



Press the green button to reset the alarm. The red LED will then turn off. If the alarm goes off once more, the same procedure can be repeated.